xteink4

- Flashing Firmware
- XTC / XTCH

Flashing Firmware

The recommended tool from the github repo is https://xteink.dve.al/

Connection Issues

Arch Linux (EndeavorOS)

If you encounter issues connecting to web serial try the following

Possible Error

> xteink (index):1 Uncaught (in promise) NetworkError: Failed to execute 'open' on 'SerialPort': Failed to open serial port.

`ls -l /dev/ttyACM0`

Check which group you are in

`crw-rw---- 1

If your user doesn't appear add the user by doing the followin g

`sudo usermod -a -G <group> <username>`

References

https://support.arduino.cc/hc/en-us/articles/360016495679-Fix-port-access-on-Linux

XTC / XTCH

XTC / XTCH is the proprietary container format that the xteink4 uses.

Converting to these formats yields better results.

Converter: https://x4converter.rho.sh